



SYNC[®]

with MyFord Touch[™]/MyLincoln Touch[™]

Quick Reference Guide



Keep your eyes on the road and hands on the wheel using SYNC with MyFord Touch/MyLincoln Touch driver-connect technology. It puts you in control of what you want when you want it — through voice, touch or a mix of both. There are also settings and controls you can personalize to suit your interests and the level of engagement you desire.


Getting Started

Begin with the most important things to do to optimize your experience.

1. Set up your Owner Account

- Go to **SyncMyRide.com**
- Select "Register"
- Follow the on-screen instructions

TIP: If you already have a Ford or Lincoln Owner Account, your information carries over.



2. Pair your phone

- Touch "Add a phone"
- Follow the on-screen instructions

TIP: Find the Bluetooth® menu on your phone and add SYNC® as a device. Enter the 6-digit PIN provided by SYNC.



3. Insert SD Card (if equipped with Navigation)

- Locate the Navigation map database package in the glove compartment
- Open package and insert the SD Card into the media hub (center console – Ford; center stack – Lincoln)



Time-saving TIP:

If you have a laptop and Wi-Fi® hotspot available, you can set up your SYNC Owner Account right in the vehicle!



Things to Do Before You Drive

Using the innovative, driver-connect technology is simple and intuitive. Over time, you will find what works best for you. Start with some basics.

1. Familiarize yourself with the basic controls

- The color and feature groups of the touch screen match the Infotainment display and work independently of each other, which allows you to show different or similar features
- Touch the 4 corners on the touch screen for quick access to the main feature groups for:
 - Phone
 - Entertainment
 - Navigation (if equipped) or SYNC® Services
 - Climate



- Touch the 5-way controls to access the available menus and sub-menus of the Infotainment display or Multifunction display, which also includes convenient squared graphics at the top to show depth and scope for how many screens there are and how far you are in
- Use the touch-sensitive Audio and Climate controls instead of the touch screen, if desired:
 - Touch the words or icons, not the light bars, to activate (Ford)
 - Slide a finger along the top of the light bar for volume and fan speed (Lincoln)

(continued on next page)

Things to Do Before You Drive (continued)

2. Set your My Temp

- Touch the Climate corner on the touch screen (blue area, lower right)
- Set your exact, desired temperature using the blue or red arrows
- Press and hold the My Temp button until the background color goes solid

TIP: Certain climate features, like heated and cooled seats (if equipped) or heated steering wheel (if equipped) are only controlled through the touch screen, not the touch-sense audio/climate bezel below.



3. Set your clock

Manually

- Touch Menu > Clock
- Touch the + or – triangles to adjust
- Touch AM or PM

Automatically

- Touch Menu > Clock
- Touch GPS Time Synchronization to On



4. Set your radio presets

Manually

- Touch the Entertainment corner on the touch screen (red area, lower left)
- Touch AM/FM
- Touch Direct Tune
- Enter the desired station and touch Enter
- When the station appears along the right side, touch and hold to save

Automatically

- Touch the Entertainment corner on the touch screen (red area, lower left)
- Touch AM/FM
- Touch Options
- Touch Auto Presets (AST) to have the system automatically store the six strongest stations in your current location



5. Set your home address for SYNC® Services

- Make sure your phone is paired and connected first
- Touch the [6-5] Voice button on the steering wheel, say “Services” and wait for the prompt
- Say “Directions to Home” and wait for the prompts to say your home address (The info is saved at **SyncMyRide.com** or you can manually enter it online)

TIP: Set My Home as nearest intersection or your home address for the voice-activated Navigation System (if equipped).

- Touch DEST on the Navigation corner (green area, upper right)
- Touch My Home
- Follow the highlighted text fields to enter any necessary information. Note that any order of entry is acceptable. For address destination entry, the Go! button will appear once all the necessary information has been entered. Pressing the Go! button will trigger the display of the address location on the map



Using Voice Commands

Virtually anything you can do by touch you can also do by voice to keep your hands on the wheel and eyes on the road. The system recognizes over 10,000 commands. Here are some of the most common ones.

Touch the  Voice button on the steering wheel, and then say:



Basic Commands

- What can I say?
- List of commands
- Main menu
- Previous
- Next
- Go back
- Exit
- Help



SYNC® Services

- Must say "Services" first, and then:
 - What are my choices?
 - Traffic
 - Directions
 - Business search
 - Favorites
 - News, sports, weather, horoscopes, stock quotes, movies or travel
 - Help



Phone

- Phone list of commands
- Dial
- Call <name> on cell/
at home/at work
- Call voicemail
- Do not disturb <On/Off>
- Listen to text message*

* Phone-dependent feature.



Climate

- Climate control list of commands
- Climate <On/Off>
- Climate my temperature
- Climate temperature <60-85> degrees



Entertainment

- Audio list of commands*
- Audio <On/Off>
- Radio
 - FM <87.7-107.9>
 - FM preset <#>
- CD
 - Play track <1-512>
 - Shuffle <On/Off>
- USB
 - Play song <name>
 - Play album <name>
- Sirius®
 - <channel name>
 - Preset <#>

* You can also get detailed lists of commands for radio, USB, Bluetooth® audio, Sirius and SD Card.



Navigation (if equipped)

- Navigation list of commands
 - Destination street address <number, name, city>
 - Destination home
 - Navigation voice <On/Off>
 - Navigation volume <increase/decrease>
 - Repeat instruction
 - Show <map/north-up/heading-up/3D>
- Travel Link™ list of commands
 - Traffic
 - Weather
 - Movie listings
 - Fuel prices
 - Sports <headlines/scores/schedules>

Please refer to the MyFord Touch™/MyLincoln Touch™ Supplement to the Owner's Guide for complete lists of voice commands.

Stay Connected While You Drive

Whether you choose to use the smaller Infotainment display in the instrument cluster or the larger center touch screen, you can easily get to what you want. You can even use your voice, too!



Phone

Make and receive calls


- Touch the Voice button on the steering wheel to make a call, then say Call <name from phonebook> or Dial <desired number>
- Touch the Phone button on the steering wheel to receive a call
- Touch and hold to end a call

TIP: You can also use either the touch screen or the Infotainment display to see who's calling you or who you call. If your phone supports it, and you have pictures associated with your contacts, you can see the picture on the touch screen.

Put your phone into Do Not Disturb mode

- Touch the Phone corner on the touch screen (yellow area, upper left)
- Touch Settings
- Touch Do Not Disturb to On

This feature blocks incoming calls or text messages and diverts calls into voicemail and saves text messages on the phone for viewing later. Unlike turning the phone Off, with this feature, you can still make outgoing calls and have the 911 Assist™ feature connect directly to a 911 Operator, if activated.



Entertainment

Voice-activate all audio sources

Gain access to any audio source whether equipped with the vehicle, like AM/FM/HD Radio™ or Sirius®, or what you bring in, like digital media player, CDs or Bluetooth® stereo through your phone.

- Touch the Voice button on the steering wheel, then say the audio source you want, for example:
 - FM or AM
 - Sirius
 - CD
 - USB
 - Bluetooth audio

* See voice commands page for more.

Tag songs in HD Radio for future purchase (if equipped w/ optional SONY® or THX® II)

- Touch the Entertainment corner of the touch screen (red area, bottom left)
- Touch AM/FM > HD Radio > On
- When listening to a song broadcasting in HD Radio (notice icon above the call station numbers), touch TAG



- Up to 100 songs can be stored on SYNC® until your iPod® is connected to retrieve the stored songs for preview and purchase when synched with iTunes®



Compass and Navigation (if equipped)

See the direction headed and next turn along a route

Standard

- Touch the 5-way control to access the Infotainment display and scroll down
- If no route is active, the menu says "Compass." If turn-by-turn directions have been downloaded through SYNC® Services, it says "Directions"

Optional

- Touch the Navigation corner of the touch screen (green area, upper right)
- If no route is active, you can activate one (see below)
- If a route is active, you can change your map view (see below)

Find a local business or address

- Use the "one shot" destination entry feature
- Touch the Voice button on the steering wheel, then say "Destination street address"
- The system will ask you to say the full address and will display an example on-screen. You can then speak the address naturally, such as: One two three four Main Street, Anytown



Choose three different routes based on your preference – Fastest, Shortest or Eco-Route

When setting a route, you have three different options of how to get there, plus can view a "Demo" of the route before you begin driving:

- Fastest Route uses the fastest moving roads possible
- Shortest Route uses the shortest distance possible
- Eco-Route uses the most fuel-efficient route

Change your map mode display

You have a full 3D Navigation experience, with the ability to change your view from 3D to always showing north up to always showing the direction headed.

- Touch the red arrow icon to adjust the view you desire



Climate

Adjust the temperature and fan speed

Use your voice, the Infotainment display, the touch screen or audio/ climate bezel. Your choice. For example:

- Touch the 5-way control to access the Infotainment display and scroll down to Climate and select
- Adjust temperature and fan speed as desired

Switch from Auto to Dual mode

- Touch the Climate corner of the touch screen (blue area, lower right)
- Touch Auto or touch Dual
- If Auto is selected and you use the My Temp feature, both sides of the cabin are set to your temperature
- If Dual is selected, the passenger can control the temperature setting independent of your selection



Adjust heated and cooled seats (if equipped)

These features can only be controlled through the touch screen.

- Touch the Climate corner of the touch screen (blue area, lower right)
- Touch icons for heated or cooled (driver or passenger)



Where to Go for More

After you've been up and running, you may wish to explore a little more about the system. To help you, there are several resources available.



SyncMyRide.com

Log on to **SyncMyRide.com** to set up a SYNC Owner Account and set preferences for Vehicle Health Report and Traffic, Directions and Information. Explore the interactive owner support available:

- Text and video-based info from feature overview to troubleshooting
- Index-card-style presentation of info, similar to a baseball card or food label
- Sharing info via email, mobile, print or Facebook



FordOwner.com

Log on to **FordOwner.com** (or **LincolnOwner.com**) to access online versions of your glove compartment materials.

- Owner's Guide
- Owner's Guide Supplement for MyFord Touch™ (or MyLincoln Touch™)
- Roadside Assistance Card
- Sirius® Satellite Information Card



Customer Assistance

To speak to someone directly, Monday through Friday, from 8:00 a.m. to 5:00 p.m. (Local Time):

- 800-392-FORD (3673)
- 800-232-5952 (TDD for the hearing impaired)
- Once connected, follow the voice prompts for SYNC by selecting #1, then #3, then #1



Additional Features to Discover

Over time, you may discover many other features to enhance your ownership experience.

- 3D carousel album cover art display
- Customizable home screen displays, including personal photos and shortcuts menus
- Internet connectivity through Wi-Fi®, USB mobile broadband or Bluetooth® tethering
- Rear view camera display
- 3D carousel ambient lighting control (if equipped)
- 3D building icons for Navigation (if equipped)
- Audible text messaging (if equipped)
- Sirius Satellite Radio with replay feature
- Send destinations to SYNC or your Navigation System from Google Maps™ or MapQuest™

Driving while distracted can result in loss of vehicle control. Only use mobile phones/MyFord Touch/MyLincoln Touch/other devices, even with voice commands, when it is safe to do so. Specifications and descriptions contained within are based upon the most current information available at time of release.

All names are trademarks and/or registered trademarks of their respective owners.

© December 2010

(10)SYNCMYTOUCH-QRG